




COWAY LOVES THE PLANET
This paper can be recycled.

TH

coway

Coway Battery-Powered Bidet BA35-A

• For your safety and proper use of the product, please read this user manual before use.



FEATURES

1

Battery-powered bidet

- Features an onboard power source and can be installed in just about any bathroom environment.



2

Simple Use with One Button (Convenience)


- Operated by battery power, simply press the button for the nozzle to extend outwards similar to an electronic bidet, which allows for thorough cleansing for both men and women.



3

Easy Battery Replacement

- With Coway's easy rotating structure applied to the back of the bidet's control panel, anyone can easily replace the batteries. (Requires 3 AA batteries)



4

Strong and Gentle Hybrid Water Flow

- Provides both a strong, wide water flow and smooth water flow from a very fine hole. Also, Coway's unique oval-shaped wide water flow cares for a wider area.



5

Nozzle Movement and Self-Cleansing

- Allows movement of the three-stage nozzle at the desired position.
- Keeps the product hygienic through automatic nozzle self-cleansing function before and after each use.



6

Slim and All-in-One Design

- The seamless design makes it easy for the water to drip when water drips onto the bidet cover with the integrated design that matches any ceramic ware or bathroom to create a neat atmosphere.



DEAR CUSTOMERS

Thank you for using our **Coway Battery-Powered Bidet.**

Please read this user manual to use and maintain the product correctly.

If you encounter a problem while using the product, Please refer to the user manual to solve the problem.

CONTENTS

Product Information

- | 03 | **Safety information**
 - Installation
 - During Use
 - Others
- | 07 | **Part names**

How to use

- | 09 | **Buttons and display panel**
- | 11 | **Using your bidet**
- | 12 | **Choosing the desired cleansing**
 - For rear cleansing
 - For front cleansing

Maintenance

- | 14 | **Installation**
 - Before the Installation
 - Remove existing toilet seat
 - Install product
- | 17 | **Cleaning**
 - Cleaning the product body
 - Cleaning the nozzle
 - Cleaning the mesh filter
- | 18 | **Maintenance**
 - Removing the product
 - Replacing the mesh filter
 - Replacing the batteries

Others

- | 21 | **Troubleshooting**
- | 23 | **Specifications**

- Please keep the user manual where it can be readily reached or found. -

SAFETY INFORMATION

Make sure to follow these instructions for your safety!

These instructions are intended to keep the users safe and prevent property damage. Please use the product correctly after reading the precautions carefully.

- ⚠ DANGER :** Death or serious injury may occur if the instruction is not followed.
- ⚠ WARNING :** Severe bodily injury or property damage may occur if the instruction is not followed.
- ⚠ CAUTION :** Minor bodily injury or property damage may occur if the instruction is not followed.

Installation

- ⚠ Do not install the product near an electric heating device.**
There is a risk of fire.
- ⚠ Do not use or store flammable gases or materials near the product.**
There is a risk of fire.
- ⚠ Do not install the product in a location that is too humid, dusty or exposed to water (rain) splashes.**
There is a risk of fire.
- ⚠ Use the tap water for water supply.**
Using the industrial water or treated water for water supply may cause skin damage or skin disease.
- ⚠ Do not use the product under direct sunlight.**
It can cause discoloration or bleaching.
- ⚠ Make sure to inspect the water source connection part after installation for any leakage.**
Make sure to fix rubber packing on the T connection pipe.



Tips

This product is only intended for use in the bathroom and should be used in accordance with the user manual. Do not use for any other purposes.

During Use

- ⚠ **Do not bring the product close to an electric heater or throw fire objects such as a burning cigarette into the toilet.**
There is a risk of product deformation or fire.
- ⚠ **Do not use the product in a highly humid place or sprinkle water on the product.**
- ⚠ **Do not push a metal wire or sharp object into a gap on the product.**
It may damage or break the product.
- ⚠ **Do not place a bowl filled with water, chemicals, food, small metal pieces, or flammable substances on top of the product.**
If foreign substances enter the product, there is a risk of electrocution or fire.
- ⚠ **Do not use the product if it is not working properly.**
 - * Close the valve of the main water supply and contact the service center.There is a risk of electrocution or fire.
- ⚠ **Before cleaning the mesh filter, close the main water supply valve.**
It may damage or break the product.
- ⚠ **Do not sit or stand on the seat cover or put heavy objects on it.**
It may damage or break the product.
- ⚠ **Do not use the control panel as a support or press it with excessive force.**
Doing so can damage or break the product.

SAFETY INFORMATION

⚠ DANGER : Death or serious injury may occur if the instruction is not followed.

⚠ WARNING : Severe bodily injury or property damage may occur if the instruction is not followed.

⚠ CAUTION : Minor bodily injury or property damage may occur if the instruction is not followed.

⚠ Do not open or close the seat cover with excessive force or lean on it.

It may damage or break the product.

⚠ Be careful not to smear the nozzle or product surface with urine.

It may cause odors or product breakdown.

⚠ Close the main water supply valve if it is not being used for a long period of time.

⚠ Make sure to use the new hose set provided with the product. Do not use an old hose set.

⚠ Persons (including children) with reduced physical, sensory or mental capabilities should be supervised or instructed to use the product.

There is a risk of bodily injury or product breakdown.

⚠ Children should be supervised to ensure that they do not play with the appliance.

There is a risk of bodily injury or product breakdown.

Others

- ⚠ **Taking a shower or cleaning the bathroom with water, make sure that the bidet's main body or control panel does not come in contact with water, detergent, etc.**

It may damage or break the product.

- * If foreign materials enter the product, close the main water valve, and call the Coway service center.

- ⚠ **Do not disassemble, repair, or modify the product on your own.**

It may damage or break the product.

- ⚠ **Do not separate the main body and seat.**

It may damage or break the product.

- ⚠ **Do not sprinkle water on the product or use thinner, benzene, chemicals, hydrochloric acid detergents, etc.**

This may result in corrosion, discoloration or scratches.


- * Wipe it up with soft cloth or sponge to clean the product.

- ⚠ **Do not pull the bidet hose or the connection hose with excessive force.**

It may cause leakage or product breakdown.

- ⚠ **Do not replace the battery with wet hands. Dry hands well before replacing the battery.**

It may damage or break the product.



Tips


- Use 3 AA-type batteries.
- Do not use new and old batteries together.
- Check +, - poles when replacing batteries.

PART NAMES

Front/Rear view



Installation kit



* The actual installation parts may not look exactly as shown.


BUTTONS AND DISPLAY PANEL

Display panel/Control panel

● Display panel ■ Control panel



BA35-A



1 Stop button

2 Rear button

3 Front button

4 Water pressure button

5 Nozzle position button

1 Low battery indicator

2 Water pressure indicator

Display panel



1 Low battery indicator

When the battery needs to be replaced, the LED flashes.



2 Water pressure indicator

Press the water pressure button to adjust the pressure between level 1 and 2.

WATER PRESSURE

Control Panel



1 Stop button

All operating functions will stop.



2 Rear button

Use this button to use the rear cleansing function.



3 Front button

Use this button to use the front cleansing function.



4 Water pressure button

Press the water pressure button to adjust the pressure between level 1 and 2.

WATER PRESSURE



5 Nozzle position button

Used to adjust the vertical position of the nozzle during the front or rear cleansing operation. Press the nozzle position button to select from the three nozzle position settings.



* The default position is level 2.

NOZZLE POSITION


USING YOUR BIDET

Seat on the seat

- Functions become available when the seat sensor is activated.
- You must sit on the seat for at least 3 seconds in order to activate the bidet.
- The sensor in the seat may not work properly depending on the way in which the user sits on the seat.
 - * If the bidet does not work, please move slightly towards the rear on the seat.
- When you move away from the bidet, all functions are automatically stopped.
- The product may not work if a little child is seated, so please sit behind the seat sensor sticker.



Wrong position



Right position

- If you sit in the wrong position, there will be no clicking sound.
- Please sit behind the seat sensor sticker.

- If you sit in the right position, there will be a clicking sound.

CHOOSING THE DESIRED CLEANSING

For rear cleansing

■ Cleansing

When seated, press the 'Rear' button.

- Cleansing water will spray for approximately 1 minute and then automatically stopped.
- Self-cleaning is performed for approximately 6 seconds after the nozzle retracts itself.
- * If the 'Rear' button is pressed again during the cleansing operation, additional rear cleansing is performed for another minute.
- * While cleansing, users can adjust water pressure according to their preference.
- * The bidet will not function without a person seated on the seat.
- * For normal operation of the product, water pressure for ejection must be 0.1 MPa (approximately 14.2 psi), above the minimum water flow standard (1 L/min).
- * The nozzle may not extend when the toilet is flushed using the lever.



■ Stop

To stop the current operation, press the 'Stop' button.

- This stops all currently operating functions.



CHOOSING THE DESIRED CLEANSING

For front cleansing

■ Cleansing

When seated, press the 'Front' button.

- Cleansing water will spray for approximately 1 minute and then automatically stopped.
- Self-cleaning is performed for approximately 6 seconds after the nozzle retracts itself.

- * If the 'Front' button is pressed again during the cleansing operation, additional front cleansing is performed for another minute.
- * While cleansing, users can adjust water pressure according to their preference.
- * The bidet will not function without a person seated on the seat.
- * For normal operation of the product, water pressure for ejection must be 0.1 MPa (approximately 14.2 psi), above the minimum water flow standard (1 L/min).
- * The nozzle may not extend when the toilet is flushed using the lever.



■ Stop

To stop the current operation, press the 'Stop' button.

- This stops all currently operating functions.



Tips



If the water pressure is too strong when you use the front or rear cleansing feature, press the water pressure button to set the lowest level (level 1).

INSTALLATION

■ Install product

Tighten the anchor nuts so the bidet is attached firmly onto the toilet.

■ Installation location

The bidet is for use in the bathroom so make sure to install it in a place where water cannot splash it directly.

■ After installation

Store the existing product away from direct sunlight.

■ Cold water pipe

Make sure to connect the bidet to a cold water pipe.




Tips

Consult with a Coway technician for the detailed installation method to ensure optimal performance of the product.

Before the Installation

Check the surface of toilet bowl to ensure the fixing bracket is placed flatly.
If toilet bowl has uneven surface, the seat sensor will not work properly.




INSTALLATION

Remove existing toilet seat


Remove the anchor nuts to detach the existing toilet seat ① and the cover ②.

* Store the removed seat and seat cover safely in a place with no direct sunlight.




Install product

1. Close the main water supply valve ① then remove the existing water tank hose ②.




2. Connect the rubber packing, the T-shaped connector and the water tank hose in order to the existing water pipes. Connect the bidet hose to the T-shaped connector.


- * Rubber packing must be inserted into every T-shaped connector.
- * Fully tighten the nuts at the top and bottom of the T-shaped connector in a clockwise direction.




3. Insert the anchor screws into the installation plate on top of the toilet and tighten the nuts so it cannot move.




4. Place the bidet on the fixing bracket.



5. Connect the bidet hose (tubing) to the T-shaped connector and the product's inlet port.




6. Turn the lever on the T-shaped connector to open it.




7. Open the main water supply valve.

- Make sure to check in the T valve connection and the bidet's inlet port for any leakage after opening the water supply valve.



8. Insert 3 new AA batteries into the battery cartridge.
(see page 19)



9. Check if the main unit is ready to operate normally.

- If the Red LED indicator on the control panel blinks, contact your COWAY service center.



CLEANING

Cleaning the product body

Use a soft cloth or sponge with a neutral detergent to clean the bidet.

- Failure to do so may result in product deformation or damage.

⚠ The product body and the controller should never be cleaned with water.



Tips

⚠ Do not use a neutral detergent or kitchen detergent that contains thinner, benzene, hydrochloric acid detergent, or abrasives.

⚠ Make sure to follow the above instructions as, unlike other surfaces, the seat is highly susceptible to scratches and rough scrubbers can scratch or peel the surface.

Cleaning the nozzle

- Gently lift and pull out the nozzle using your hand until you have clear view of it.

- Clean the nozzle using a neutral detergent with a soft sponge or brush.



Tips

⚠ Gently hold onto the nozzle as you clean it. Applying excessive force to the nozzle may damage the nozzle and cause it to malfunction.

Cleaning the mesh filter

When the water pressure gets low, it is time to clean the water supply mesh filter.




Tips

⚠ Do not remove the mesh filter with the main valve in the open position.

Thoroughly rinse the mesh filter under running water.

- For better results, remove any buildup of foreign substances from the filter using a brush.


- Using excessive force to clean the filter may damage it.




MAINTENANCE

Removing the product

1. Close the main water supply valve.




2. Pull the product forwards by holding both sides of the product while pressing the button at the bottom right of the product, to separate the product from the installation plate.




Replacing the mesh filter

When the water pressure gets low or the product has been used for a long time, replace the old mesh filter into a new one.

1. Remove the used mesh filter on the bottom of the product using a (-) screwdriver.




2. Replacing the new mesh filter.



3. Reattach the new mesh filter to the product.



- When reattaching the mesh filter, make sure that the rubber packing (2 EA) does not come out.





MAINTENANCE

Replacing the batteries

1. After removing the cover, remove 2 screws to open the battery lid.





2. Rotate the battery cartridge assembly 90 degrees.




3. Remove 3 AA batteries in the battery cartridge and insert 3 new AA batteries.



- Check +, - poles when replacing the batteries.




4. Rotate the battery cartridge cap on the control panel to close it. After rotating the cartridge cap, assemble it by rotating to the fully tightened position.



* After replacing the battery, make sure the main body and the cartridge cap are fully engaged.



5. Close the cover of the control panel battery and fasten the 2 screws to close the lid.



Tips

Always adhere to the following precautions to prevent ruptured batteries and battery acid leakage.

- ⚠ Always use new versions of the same type battery type each time you replace batteries.
- ⚠ Remove the battery from the battery compartment when not using the product for extended periods of time.
- ⚠ Do not use rechargeable batteries.
- ⚠ Do not expose to fire.
- ⚠ Do not replace them with wet hands when replacing the batteries.
- ⚠ Life period of the bidet may vary depending on the battery's manufacturer, type, and capacity.
- ⚠ Replace the batteries if the battery discharge indicator lamp blinks.

TROUBLESHOOTING

The bidet may operate abnormally due to minor causes not because of a product malfunction but because the user is unfamiliar with using the product. In such a case, problems can be easily solved even without the help of the Service Center by checking the following. If you cannot solve the problem after checking the following items, please call the Service Center.

Symptom	Check	Solution
The product is not functioning at all.	• Is the low battery LED flashing?	Replace the new battery.
	• Is the battery inserted normally?	Please check the insertion positions (+,-).
	• Is the seat sensor working properly?	Refer to seat sensor instructions. (see page 11)
There is no water coming out of the nozzle.	• Is the main water supply valve closed?	Open the main water supply valve.
	• Is the nozzle clogged?	Unclog the nozzle using a brush.
	• The bidet has been installed, but there's no water coming out of the nozzle.	Check if your water has been shut off. Check if the handle valve is in the locked position.
The water pressure is too low.	• Is the water pressure setting too low?	Adjust the water pressure setting.
	• Is the nozzle clogged?	Unclog the nozzle using a brush.
	• Is the water supply mesh filter dirty?	Clean the mesh filter. (see page 17)
Water continues to come out after stop is pressed.	• Water is leaking from the bidet hose.	Push the bidet hose all the way in.
Water is leaking, but not from the nozzle.	• Water is used to clean the nozzle after cleansing. This is not a malfunction.	
	• Water beads can sometimes form around the nozzle. Water beads formed at the bottom of the product after cleaning the nozzle may drip into the bowl. This is not a malfunction.	
The buttons are not responding.	• Are you seated on the bidet?	The bidet's features are only active when there is a person seated on the bidet.
	• Is the handle valve located on the side of the bidet in the released position?	If the handle valve is in the locked position, the nozzle will not extend.

Symptom	Check	Solution
The control panel does not work.	• Do the batteries need replacing?	Replace the batteries.
	• Are the batteries inserted the in the correct position(+/-)?	Reinsert the batteries in the correct positions.
	• Is the toilet seat sensor working properly?	Refer to the seat sensor instructions.
Even though the seat is not occupied, the cleansing operate when you press the button.	• Something get jammed in hinge of seat.	Remove the jammed objects.

SPECIFICATIONS

Product name	Coway Battery-Powered Bidet
Model	BA35-A
Feed water pressure	0.1 MPa - 0.49 MPa (14.2 psi - 71 psi), Feed water pressure(more than 1 L/min)
Dimensions	449.5 mm (Width) X 505.5 mm (Depth) X 130.5 mm (Height)
Weight	3.45 kg
Rear cleansing	Minimum 800 mL/min, automatic nozzle self-cleaning function
Front cleansing	minimum 800 mL/min, automatic nozzle self-cleaning function
Standard time	Rear cleansing 1 minute, front cleansing 1 minute
Water pressure control	2 level
Nozzle position	3 level
Installation parts	2 anchor screws, 2 anchor rubbers, 2 anchor washers, 2 anchor nuts 1 bidet hose, 1 cover screw, 1 Installation plate, 2 fixing sliders, 1 Rubber packing, 1 T-shaped connector, 3 batteries (AA)
Operating temperature	0 ℃ ~ 40 ℃

► The specifications are subject to change for the purpose of improving product performance.

THAILAND
Add : Coway (Thailand) Co., Ltd. 75/104-106 Ocean Tower 2 38th Fl, Soi Sukhumvit 19 (Wattana), Sukhumvit Road, Klongtoey Nua, Wattana, Bangkok 10110 Call center : 1421

MEMO

////////////////////////////////////

ฟีเวอร์

1

ปิดระบบพลังงานแบตเตอรี่


- มีแหล่งพลังงานในตัว และสามารถติดตั้งในห้องน้ำที่มีสภาพแวดล้อมต่างๆ เกือบทุกรูปแบบ



2

การใช้งานอย่างง่ายด้วยปุ่มเดียว (ตามสะดวก)


- ทำงานด้วยพลังงานแบตเตอรี่ เพียงแค่กดปุ่มให้หัวฉีดขึ้นออกคล้ายกับกับไอซ์ราเร่ล้าง อีเล็กทรอนิกส์ ซึ่งทำการชำระล้างอย่างหมดจดสำหรับทั้งผู้ชายและผู้หญิง



3

การเปลี่ยนแบตเตอรี่อย่างง่ายดาย

- ด้วยโครงสร้างแบบหมุน ได้อย่างสะดวกที่ด้านหลังของแผงควบคุมของไอซ์ราเร่ล้าง Coway ทุกคนสามารถเปลี่ยนแบตเตอรี่ ได้อย่างง่ายดาย (ใช้แบตเตอรี่ขนาด AA จำนวน 3 ก้อน)



4

กระแสน้ำแบบผสมที่แรงนุ่มนวล

- ให้กระแสน้ำที่แรง กว้าง และนุ่มนวลจากรูขนาดเล็กมาก กระแสน้ำทรงรีมุมกว้างของ Coway สามารถชำระล้างบริเวณที่กว้างขึ้น



5

การเคลื่อนไหวของหัวฉีดและการทำความสะอาด

- สามารถเคลื่อนย้ายหัวฉีดมากระยะไปยังตำแหน่งที่ต้องการ
- รักษาความสะอาดของผลิตภัณฑ์ด้วยฟังก์ชันทำความสะอาดหัวฉีดอัตโนมัติก่อนและหลังการใช้งานแต่ละครั้ง



6

การออกแบบที่บางเฉือนลิ้น

- การออกแบบอย่างไรรวดร้อทำให้พื้นที่ที่หยดลงบนฝารองนั่งไหลออกอย่างง่ายดาย ซึ่งเป็นการออกแบบที่เข้ากันได้กับสุขภัณฑ์เซรามิกทุกชนิด และทำให้ห้องน้ำดูสะอาดเรียบร้อย



เรียนลูกค้า

ขอขอบพระคุณที่ใช้ **โล่ชำระล้างพลังงานแบตเตอรี่ Coway** ของเรา

โปรดอ่านคู่มือผู้ใช้ฉบับนี้ เพื่อการใช้งานและการดูแลรักษาผลิตภัณฑ์อย่างถูกต้อง

หากท่านพบปัญหาใดๆ ระหว่างการใช้งานผลิตภัณฑ์นี้ โปรดอ้างอิงคู่มือผู้ใช้เพื่อแก้ไขปัญหา

เนื้อหา

ข้อมูลผลิตภัณฑ์

- | 03 | ข้อมูลความปลอดภัย
 - การติดตั้ง
 - ระหว่างการใช้งาน
 - อื่นๆ
- | 07 | ข้อควรระวัง

วิธีการใช้งาน

- | 09 | ปุ่มและหน้าจอ
- | 11 | การใช้งานโล่ชำระล้างพลังงานของท่าน
- | 12 | การเลือกการชำระล้างที่ต้องการ
 - สำหรับการชำระล้างด้านหลัง
 - สำหรับการชำระล้างด้านหน้า

การซ่อมบำรุง

- | 14 | การติดตั้ง
 - ก่อนทำการติดตั้ง
 - ถอดฝาครอบนึ่งเค็มออก
 - ติดตั้งผลิตภัณฑ์
- | 17 | การทำความสะอาด
 - การทำความสะอาดตัวผลิตภัณฑ์
 - การทำความสะอาดหัวฉีด
 - การทำความสะอาดตะแกรงฟیلเตอร์
- | 18 | การซ่อมบำรุง
 - การถอดผลิตภัณฑ์ออก
 - การเปลี่ยนตะแกรงฟیلเตอร์
 - การเปลี่ยนแบตเตอรี่

อื่นๆ

- | 21 | การแก้ไขปัญหา
- | 23 | ข้อมูลจำเพาะ

ข้อมูลความปลอดภัย

อย่าลืมปฏิบัติตามคำแนะนำเหล่านี้เพื่อความปลอดภัยของท่าน

คำแนะนำเหล่านี้มีวัตถุประสงค์เพื่อให้ความปลอดภัยแก่ผู้ใช้และป้องกันทรัพย์สินเสียหาย โปรดใช้ผลิตภัณฑ์นี้อย่างถูกต้องหลังจากอ่านข้อควรระวังโดยละเอียด

- ⚠️ **อันตราย :** หากไม่ปฏิบัติตามคำแนะนำ อาจทำให้เกิดอันตรายถึงแก่ชีวิตหรือการบาดเจ็บได้
- ⚠️ **คำเตือน :** หากไม่ปฏิบัติตามคำแนะนำ อาจทำให้เกิดการบาดเจ็บร้ายแรงหรือทรัพย์สินเสียหายได้
- ⚠️ **ระวัง :** หากไม่ปฏิบัติตามคำแนะนำ อาจทำให้เกิดการบาดเจ็บเล็กน้อยหรือทรัพย์สินเสียหายได้

การติดตั้ง

- ⚠️ **อย่าติดตั้งไว้ใกล้กับอุปกรณ์ทำความร้อนไฟฟ้า**
เนื่องจากมีความเสี่ยงต่อการเกิดเพลิงไหม้
- ⚠️ **อย่าใช้หรือเก็บก๊าซหรือวัตถุไวไฟไว้ใกล้กับผลิตภัณฑ์**
เนื่องจากมีความเสี่ยงต่อการเกิดเพลิงไหม้
- ⚠️ **อย่าติดตั้งผลิตภัณฑ์ในจุดที่มีความชื้นสูงเกินไป มีฝุ่นมาก หรือมีน้ำ (ฝน) กระเซ็น**
เนื่องจากมีความเสี่ยงต่อการเกิดเพลิงไหม้
- ⚠️ **ใช้น้ำประปาเป็นแหล่งจ่ายน้ำ**
การใช้น้ำเพื่ออุตสาหกรรมหรือน้ำที่ผ่านการบำบัดอาจ ทำให้ผิวหนังเสียหายหรือเกิดโรคผิวหนังได้
- ⚠️ **อย่าใช้ผลิตภัณฑ์ในแสงแดด**
เนื่องจากอาจทำให้สัฟไฟต์ขึ้นหรือสีซีด
- ⚠️ **อย่าลืมตรวจสอบชิ้นส่วนข้อต่อแหล่งจ่ายน้ำว่ามีการรั่วไหลหรือไม่** หลังจากการติดตั้ง
อย่าลืมใส่แหวนยางเข้ากับข้อต่อท่อสามทาง



คำแนะนำ

ผลิตภัณฑ์นี้มีวัตถุประสงค์เพื่อการใช้งานในห้องน้ำเท่านั้น และควรใช้งานตามที่ระบุไว้ในคู่มือผู้ใช้นั้น อย่าใช้ผลิตภัณฑ์นี้เพื่อวัตถุประสงค์อื่นๆ

ระหว่างการใช้งาน

- ▲ **อย่านำผลิตภัณฑ์ไปใกล้กับเครื่องทำความร้อนไฟฟ้า หรือทิ้งวัสดุติดไฟเช่นบุหรี่ลงไป**
ในโถส้วม
เนื่องจากมีความเสี่ยงที่ผลิตภัณฑ์จะเสีรูปทรงหรือเกิดเพลิงไหม้
- ▲ **อย่าใช้ผลิตภัณฑ์ในสถานที่ซึ่งมีความชื้นสูง หรือมีน้ำกระเซ็นใส่ผลิตภัณฑ์**
- ▲ **อย่าสอดลวดโลหะหรือวัตถุมีคมเข้าไปในรอยต่อของผลิตภัณฑ์**
เนื่องจากอาจทำให้ผลิตภัณฑ์เสียหายได้
- ▲ **อย่าวางขาไม้ ผ้า เสาเคมี อาหาร โลหะชิ้นเล็กๆ หรือวัตถุไวไฟไว้บนผลิตภัณฑ์**
หากมีวัตถุแปลกปลอมเข้าไปในผลิตภัณฑ์ จะทำให้มีความเสี่ยงที่จะเกิด ไฟฟ้าช็อตหรือเพลิงไหม้
- ▲ **อย่าใช้งานผลิตภัณฑ์หากผลิตภัณฑ์ทำงานผิดปกติ**
* ปิดวาล์วแหล่งจ่ายน้ำหลัก แล้วติดต่อศูนย์บริการ เนื่องจากมีความเสี่ยงต่อการเกิด ไฟฟ้าช็อตหรือเพลิงไหม้
- ▲ **ก่อนที่จะทำความสะอาดตะแกรงฟیلเตอร์ ให้ปิดวาล์วแหล่งจ่ายน้ำหลักก่อน**
เนื่องจากอาจทำให้ผลิตภัณฑ์เสียหายได้
- ▲ **อย่านั่ง ยืน หรือวางของหนักไว้บนฝารองนั่ง**
เนื่องจากอาจทำให้ผลิตภัณฑ์เสียหายได้
- ▲ **อย่าใช้แผงควบคุมเป็นจุดรองรับน้ำหนัก หรือกดแผงควบคุมด้วยความรุนแรงเกินไป**
การทำเช่นนั้นอาจทำให้ผลิตภัณฑ์เสียหายได้


ข้อมูลความปลอดภัย

- ⚠️ **อันตราย** : หากไม่ปฏิบัติตามคำแนะนำ อาจทำให้เกิดอันตรายถึงแก่ชีวิตหรือการบาดเจ็บได้
- ⚠️ **คำเตือน** : หากไม่ปฏิบัติตามคำแนะนำ อาจทำให้เกิดการบาดเจ็บร้ายแรงหรือทรัพย์สินเสียหายได้
- ⚠️ **ระวัง** : หากไม่ปฏิบัติตามคำแนะนำ อาจทำให้เกิดการบาดเจ็บเล็กน้อยหรือทรัพย์สินเสียหายได้

- ⚠️ **อย่าเปิดหรือปิดฝารองนั่งอย่างรุนแรงหรือยื่นพิงฝารองนั่ง**
เนื่องจากอาจทำให้ผลิตภัณฑ์เสียหายได้
- ⚠️ **ระวังอย่าให้ปัสสาวะเปื้อนหัวฉีดหรือพื้นผิวของผลิตภัณฑ์**
เนื่องจากอาจทำให้เกิดกลิ่นเหม็นหรือผลิตภัณฑ์เสียหาย
- ⚠️ **ปิวาล้วจ้ยน้ำหลักหากจะไม่ใช่ผลิตภัณฑ์ เป็นระยะเวลานาน**
- ⚠️ **โปรดใช้ชุดท่อน้ำใหม่ที่มาพร้อมกับผลิตภัณฑ์ อย่าใช้ชุดท่อเก่า**
- ⚠️ **บุคคล (รวมถึงเด็ก) ที่มีความบกพร่องทางร่างกาย การรับรู้ หรือสติปัญญา ควรได้รับการกำกับดูแลในการใช้งาน ผลิตภัณฑ์นี้**
เนื่องจากมีความเสี่ยงที่จะเกิดการบาดเจ็บหรือผลิตภัณฑ์เสียหาย
- ⚠️ **เด็กควรได้รับการกำกับดูแลเพื่อทำให้แน่ใจว่าจะไม่เล่นกับเครื่องใช้ไฟฟ้านี้**
เนื่องจากมีความเสี่ยงที่จะเกิดการบาดเจ็บหรือผลิตภัณฑ์เสียหาย

อื่นๆ

- ⚠ เมื่ออาบน้ำหรือเมื่อใช้น้ำทำความสะอาดห้องน้ำ ระวังอย่าให้ไอระเหยลงหรือแขวน
ควบคุม สัมผัสกับน้ำ น้ำยาทำความสะอาด ฯลฯ
เนื่องจากอาจทำให้ผลิตภัณฑ์เสียหายได้
* หากมีสิ่งแปลกปลอมเข้าไปในผลิตภัณฑ์ ให้ปิดวาล์วน้ำ และติดต่อศูนย์บริการ Coway
- ⚠ อย่าถอดประกอบ ซ่อมแซมหรือดัดแปลงผลิตภัณฑ์ด้วยตนเอง
เนื่องจากอาจทำให้ผลิตภัณฑ์เสียหายได้
- ⚠ อย่าแยกตัวผลิตภัณฑ์ออกจากฝารองนั่ง
เนื่องจากอาจทำให้ผลิตภัณฑ์เสียหายได้
- ⚠ อย่าฉีดน้ำบนผลิตภัณฑ์ หรือใช้ทินเนอร์ เบนซิน สารเคมี สารทำความสะอาดประเภท
กรดไฮโดรคลอริก ฯลฯ
เพราะอาจทำให้เกิดการกัดกร่อน สีผิดเพี้ยน หรือรอยขีดข่วน
* ใช้ผ้านุ่มหรือฟองน้ำเช็ดทำความสะอาดผลิตภัณฑ์
- ⚠ อย่าดึงท่อหรือข้อต่อท่อของโถชำระล้าง อย่างรุนแรงเกินไป
เนื่องจากอาจทำให้เกิดการรั่วไหลหรือผลิตภัณฑ์เสียหาย
- ⚠ อย่าเปลี่ยนแบตเตอรี่ด้วยมือที่เปียก เช็ดมือให้แห้งก่อนเปลี่ยน แบตเตอรี่
เนื่องจากอาจทำให้ผลิตภัณฑ์เสียหายได้



คำแนะนำ











- ใช้แบตเตอรี่ AA 3 ก้อน
- อย่าใช้แบตเตอรี่ใหม่และเก่ารวมกัน
- ตรวจสอบขั้ว +, - เมื่อทำการเปลี่ยนแบตเตอรี่

ชื่อชิ้นส่วน

มุมมองด้านหน้า/หลัง



ชุดติดตั้ง




* ชิ้นส่วนสำหรับการติดตั้งอาจดูไม่เหมือนในภาพ

ปุ่มและหน้าจอ


หน้าจอ/แผงควบคุม

● หน้าจอ

■ แผงควบคุม



BA35-A



1 ปุ่มหยุด

2 ปุ่มด้านหลัง

3 ปุ่มด้านหน้า (Front)

4 ปุ่มแรงดันน้ำ

5 ปุ่มปรับตำแหน่งหัวฉีด

1 ตัวชี้บอกแบตเตอรี่ต่ำ

2 ตัวชี้บอกแรงดันน้ำ

หน้าจอ



1 ตัวชี้บอกแบตเตอรี่ต่ำ

เมื่อจำเป็นต้องเปลี่ยนแบตเตอรี่ ไฟ LED จะกะพริบ



2 ตัวชี้บอกแรงดันน้ำ

กดปุ่มแรงดันน้ำเพื่อปรับแรงดันจาก 1 ถึง 2

WATER PRESSURE

แผงควบคุม



1 ปุ่มหยุด

ฟังก์ชันที่ทำงานอยู่ทั้งหมดจะหยุด



2 ปุ่มด้านหลัง

กดปุ่มนี้เพื่อใช้งานฟังก์ชันชำระล้างด้านหลัง



3 ปุ่มด้านหน้า (Front)

กดปุ่มนี้เพื่อใช้งานฟังก์ชันชำระล้างด้านหน้า



4 ปุ่มแรงดันน้ำ

กดปุ่มแรงดันน้ำเพื่อปรับแรงดันจาก 1 ถึง 2

WATER PRESSURE



NOZZLE POSITION

5 ปุ่มปรับตำแหน่งหัวฉีด



ใช้สำหรับปรับตำแหน่งแนวตั้งของหัวฉีดระหว่างการชำระล้างด้านหน้าหรือด้านหลัง กดปุ่มปรับตำแหน่งหัวฉีดเพื่อเลือกการตั้งค่าหัวฉีดสามตำแหน่ง

* ค่าที่ตั้งเริ่มต้นคือระดับ 2

การใช้งานโถชำระล้างของท่าน


นั่งบนฟารองนั่ง

- ฟังก์ชันต่างๆ จะใช้งานได้เมื่อเซ็นเซอร์ฟารองนั่งถูกเปิดใช้งาน
- ท่านต้องนั่งบนฟารองนั่งอย่างน้อย 3 วินาทีเพื่อเปิดใช้งานโถชำระล้าง
- เซ็นเซอร์ในฟารองนั่งอาจไม่ทำงานอย่างเหมาะสม ทั้งนี้ขึ้นอยู่กับวิธีที่ผู้นั่งบนฟารองนั่ง
 - * หากโถชำระล้างไม่ทำงาน โปรดขับไปทางด้านหลังของฟารองนั่งเล็กน้อย
- เมื่อท่านลุกออกจากโถชำระล้าง ฟังก์ชันทั้งหมดจะหยุดทำงานโดยอัตโนมัติ
- ผลลัพธ์ที่อาจไม่ทำงานหากเด็กเล็กนั่ง ดังนั้นโปรดนั่งข้างหลังสติกเกอร์เซ็นเซอร์ฟารองนั่ง



ตำแหน่งไม่ถูกต้อง

- หากท่านนั่งในตำแหน่งที่ไม่ถูกต้อง จะไม่มีเสียงคลิกดังขึ้น
- โปรดนั่งข้างหลังสติกเกอร์เซ็นเซอร์ฟารองนั่ง



ตำแหน่งถูกต้อง

- หากท่านนั่งในตำแหน่งที่ถูกต้อง จะมีเสียงคลิกดังขึ้น

การเลือกการชำระล้างที่ต้องการ

สำหรับการชำระล้างด้านหลัง

■ การชำระล้าง

เมื่อนั่งลงแล้ว ให้กดปุ่มด้านหลัง 'Rear'

- น้ำชำระล้างจะฉีดประมาณ 1 นาที แล้วหยุดโดยอัตโนมัติ
- การทำความสะอาดตนเองจะทำงานประมาณ 6 วินาที หลังจากหัวฉีดหดรูดกลับ
- * หากกดปุ่มด้านหลัง 'Rear' อีกครั้งระหว่างการชำระล้าง จะดำเนินการชำระล้างเพิ่มเติมอีกหนึ่งนาที
- * ในขณะที่ชำระล้าง ผู้ใช้สามารถปรับแรงดันน้ำได้ตามความชอบ
- * โถชำระล้างจะไม่ทำงาน หากไม่มีคนนั่งอยู่บนฝารองนั่ง
- * เพื่อให้ผลิตภัณฑ์ทำงานได้ตามปกติ แรงดันน้ำฉีดต้องเป็น 0.1 MPa (ประมาณ 14.2 psi) สูงกว่ามาตรฐานการไหลของน้ำขั้นต่ำ (1 L/min)
- * หัวฉีดอาจไม่ขึ้นออกเมื่อกดชักโครกด้วยคันโยก



■ หยุด (Stop)

หยุดการทำงานปัจจุบันได้โดยการกดปุ่มหยุด 'Stop'

- หยุดการทำงานปัจจุบันทั้งหมด



การเลือกการชำระล้างที่ต้องการ

สำหรับการชำระล้างด้านหน้า

■ การชำระล้าง

เมื่อนั่งลงแล้ว ให้กดปุ่มด้านหน้า 'Front'

- น้ำชำระล้างจะฉีดประมาณ 1 นาที แล้วหยุดโดยอัตโนมัติ
- การทำความสะอาดตนเองจะทำงานประมาณ 6 วินาที หลังจากหัวฉีดหดรูดกลับ
 - * หากกดปุ่มด้านหน้า 'Front' อีกครั้งระหว่างการชำระล้าง จะดำเนินการชำระล้างเพิ่มเติมอีกหนึ่งนาที
 - * ในขณะที่ชำระล้าง ผู้ใช้สามารถปรับแรงดันน้ำได้ตามความชอบ
 - * โถชำระล้างจะไม่ทำงาน หากไม่มีคนนั่งอยู่บนฝารองนั่ง
 - * เพื่อให้ผลผลิตกังหันทำงานได้ตามปกติ แรงดันน้ำฉีดต้องเป็น 0.1 MPa (ประมาณ 14.2 psi) สูงกว่ามาตรฐานการไหลของน้ำขั้นต่ำ (1 L/min)
 - * หัวฉีดอาจไม่ขึ้นออกเมื่อกดชักโครกด้วยคันโยก



■ หยุด (Stop)

หยุดการทำงานปัจจุบันได้โดยการกดปุ่มหยุด 'Stop'

- หยุดการทำงานปัจจุบันทั้งหมด



คำแนะนำ

- ⚠ หากแรงดันน้ำสูงเกินไป เมื่อท่านใช้ฟังก์ชันการชำระล้างด้านหน้าหรือด้านหลัง ให้กดปุ่มแรงดันน้ำแล้วตั้งไปที่ระดับต่ำสุด (ระดับ 1)

การติดตั้ง

■ ติดตั้งผลิตภัณฑ์

ชั้นนี้อตทุกเพื่อให้โธชำระล้างติดกับโธสัวอย่างแน่นหนา

■ สถานที่ตั้ง

โทษระงับนี้เป็นผลลักษณะสำหรับใช้ในห้องน้ำ ดังนั้นโปรดทำให้แน่ใจว่าติดตั้งมันในจุดที่จะไม่ถูกน้ำกระเซ็นใส่โดยตรง

■ หลังจากติดตั้ง

จัดเก็บผลิตภัณฑ์เดิมไว้ให้ห่างจากแสงแดด

■ ท่อน้ำเย็น

อย่าลืมต่อโออาร์ะล่างเข้ากับท่อน้ำเย็น




คำแนะนำ

ปริญญาช่างเทคนิคของ Coway สำหรับรายละเอียดวิธีการติดตั้ง เพื่อให้แน่ใจว่าผลิตภัณฑ์สามารถทำงานได้อย่างเต็มประสิทธิภาพ

ก่อนทำการติดตั้ง

ตรวจสอบพื้นผิวของโถสุกักน้ำเพื่อให้แน่ใจว่าแบร็กเก็ตยึดแน่นถูกจัดวางอย่างสนิท หากโถสุกักน้ำมีพื้นผิวที่ไม่เรียบ เช่นเซอร์ฟารอนนังอาจจะไม่ทำงานอย่างเหมาะสม




การติดตั้ง

ถอดฟารองนั่งเดิมออก


ถอดน็อตยึดเพื่อถอดฟารองนั่งเดิม ① และฝาครอบออก ②

* จัดเก็บฟารองนั่งและฝาครอบที่ถอดออกไว้อย่างปลอดภัยและไม่สัมผัสกับแสงแดดโดยตรง



ติดตั้งพลิตัมภ์


1. ปิดวาล์วจ่ายน้ำหลัก ① จากนั้นให้ถอดท่อน้ำเดิมออก ②




2. ต่อแท่งกึ่งยาง ข้อต่อสามทาง และท่อถังเก็บน้ำเข้ากับท่อน้ำที่มีอยู่ตามลำดับ ต่อท่อของโถชำระล้างเข้ากับข้อต่อสามทาง

* ต้องใส่แท่งกึ่งยางที่ข้อต่อสามทางทุกจุด


* ขันน็อตที่ด้านล่างและด้านบนของข้อต่อสามทางตามเข็มนาฬิกาให้แน่นหนา




3. ใส่สกรูยึดเข้าไปในเพลตติดตั้งที่ด้านบนของสุขภัณฑ์ แล้วขันน็อตให้แน่นเพื่อมิให้มีการเคลื่อนไหว




4. วางโถชำระล้างบนเบร็กเก็ตยึด



5. ต่อท่อโถชำระล้าง (ชุดท่อ) เข้ากับข้อต่อสามทางและช่องน้ำเข้าของผลิตภัณฑ์




6. โยคกันโยกบนข้อต่อสามทางเพื่อเปิด




7. เปิดวาล์วจ่ายน้ำหลัก

- อย่าลืมตรวจสอบข้อต่อสามทางและช่องน้ำเข้าของโถชำระล้างว่ามีการรั่วไหลหรือไม่ หลังจากเปิดวาล์วจ่ายน้ำ



8. ใส่แบตเตอรี่ AA 3 ก้อนเข้าไปในถาดแบตเตอรี่ (ดูหน้า 19)



9. ตรวจสอบว่าตัวเครื่องพร้อมทำงานตามปกติหรือไม่

- หากตัวรีบอไฟ LED สีแดงบนแผงควบคุมกะพริบ โปรดติดต่อศูนย์บริการ COWAY ของท่าน



การทำตามสะดวก

การทำตามสะดวกตัวผลิตภัณฑ์

ใช้ผ้านุ่มหรือฟองน้ำและน้ำยาทำความสะอาดที่เป็นกลางทำความสะอาดผลิตภัณฑ์

- การ ไม่ปฏิบัติตามอาจทำให้ผลิตภัณฑ์บิดเบี้ยวหรือเสียหาย

⚠ ไม่ควรใช้น้ำทำความสะอาดตัวผลิตภัณฑ์และอุปกรณ์ควบคุม



คำแนะนำ


⚠ อย่าใช้ผงซักฟอกที่เป็นกลางหรือน้ำยาทำความสะอาดห้องครัวที่มีทินเนอร์ เบนซิน สารทำความสะอาดประเภทกรดไฮโดรคลอริก หรือวัสดุผงขัด

⚠ โปรดปฏิบัติตามคำแนะนำด้านบนนี้ เนื่องจากพื้นผิวของฟารองนึ่งนี้ลอกและเกิดรอยขีดข่วนได้ง่ายมาจากการใช้อุปกรณ์ขัด

การทำตามสะดวกหัวฉีด

- ยกแล้วดึงหัวฉีดออกมาเบาๆ ด้วยมือ จนท่านเห็นหัวฉีดอย่างชัดเจน

- ทำความสะอาดโดยใช้น้ำยาทำความสะอาดที่เป็นกลางและฟองน้ำหรือแปรงที่นุ่ม



คำแนะนำ

⚠ จับหัวฉีดเบาๆ ในขณะที่ท่านทำความสะอาด การใช้ความรุนแรงเกินไปกับหัวฉีดอาจทำให้หัวฉีดเสียหาย และทำให้เกิดการทำงานผิดพลาด

การทำตามสะดวกตะแกรงฟิลเตอร์

เมื่อแรงดันน้ำลดลง ก็ถึงเวลาทำความสะอาดตะแกรงฟิลเตอร์ของแหล่งจ่ายน้ำ




คำแนะนำ

⚠ อย่าถอดตะแกรงฟิลเตอร์ในขณะที่วาล์วน้ำหลักอยู่ในตำแหน่งเปิด

ล้างตะแกรงฟิลเตอร์โดยผ่านน้ำที่กักถังไหล

- เพื่อผลลัพธ์ที่ดีขึ้น ให้กำจัดคราบสะสมจากฟิลเตอร์โดยใช้แปรง


- การใช้ความรุนแรงเกินไปในการทำมาสะอาดฟิลเตอร์อาจทำให้ฟิลเตอร์เสียหายได้




การซ่อมบำรุง

การถอดปลั๊กหัวออก

1. ปิดวาล์วจ่ายน้ำหลัก




2. ดึงผลิตภัณฑ์ไปด้านหลังโดยการจับทั้งสองด้านของผลิตภัณฑ์พร้อมกับกดปุ่มที่ด้านล่างขวาของผลิตภัณฑ์เพื่อแยกผลิตภัณฑ์ออกจากเพลตติดตั้ง




การเปลี่ยนตะแกรงฟیلเตอร์

เมื่อแรงดันน้ำต่ำหรือเมื่อใช้งานผลิตภัณฑ์มาเป็นเวลานาน ให้เปลี่ยนตะแกรงฟیلเตอร์ใหม่

1. ถอดตะแกรงฟیلเตอร์ที่ด้านล่างของผลิตภัณฑ์โดยใช้ไขควง (-)




2. การเปลี่ยนตะแกรงฟیلเตอร์ใหม่



3. ประกอบตะแกรงฟیلเตอร์อันใหม่เข้ากับผลิตภัณฑ์



- เมื่อประกอบตะแกรงฟیلเตอร์กลับคืน ตรวจสอบให้แน่ใจว่าเพ็กกิ้งยาง (2 ชิ้น) ไม่หลุดออกมา





การซ่อมบำรุง

การเปลี่ยนแบตเตอรี่

1. หลังจากถอดฝาครอบแล้ว ให้ถอดสกรู 2 ตัวเพื่อเปิดฝาครอบแบตเตอรี่





2. หมุนชุดประกอบถลับแบตเตอรี่ 90 องศา




3. ถอดแบตเตอรี่ AA 3 ก้อนออกจากถลับแบตเตอรี่ แล้วใส่แบตเตอรี่ AA ใหม่ 3 ก้อนเข้าไป



- ตรวจสอบขั้ว +, - เมื่อทำการเปลี่ยนแบตเตอรี่




4. หมุนฝาครอบตลับแบตเตอรี่บนแผงควบคุมเพื่อเปิด หลังจากหมุนฝาตลับ แล้ว ให้ประกอบเข้าโดยการหมุนจนถึงตำแหน่งที่แน่นหนา



* หลังจากเปลี่ยนแบตเตอรี่แล้ว ให้ตรวจสอบว่าตัวผลิตภัณฑ์และฝาตลับประกบกันอย่างแน่นหนา



5. ปิดฝาครอบแบตเตอรี่แผงควบคุม แล้วขันสกรู 2 ตัวเพื่อปิดฝา



คำแนะนำ

โปรดปฏิบัติตามข้อควรระวังต่อไปนี้เพื่อป้องกันมิให้แบตเตอรี่ระเบิดหรือการลัดวงจรของแบตเตอรี่รั่วไหลออกมา

- ⚠ ใช้แบตเตอรี่ใหม่ที่เป็นชนิดเดียวกันทุกครั้งที่เปลี่ยนแบตเตอรี่
- ⚠ ถอดแบตเตอรี่ออกจากช่องใส่แบตเตอรี่เมื่อจะไม่ใช้งานผลิตภัณฑ์เป็นเวลานาน
- ⚠ อย่าใช้แบตเตอรี่แบบชาร์จได้
- ⚠ อย่าให้สัมผัสกับไฟ
- ⚠ อย่าเปลี่ยนแบตเตอรี่ในขณะที่มือเปียก
- ⚠ อายุการใช้งานของโลหะอาจแตกต่างกันไปโดยขึ้นอยู่กับผู้ผลิต ชนิด และความจุของแบตเตอรี่
- ⚠ เปลี่ยน แบตเตอรี่เมื่อไฟตัวชี้บอกแบตเตอรี่ต่ำกะพริบ

การแก้ไขปัญหา

ไอซาระล้างอาจทำงานผิดปกติเนื่องจากสาเหตุเพียงเล็กน้อย มิใช่เป็นเพราะว่าผลิตภัณฑ์ทำงานผิดพลาด เพียงแต่ผู้ใช้ยังไม่ชินกับการใช้งานผลิตภัณฑ์เท่านั้น ในกรณีดังกล่าว ท่านสามารถแก้ปัญหาได้อย่างง่ายดายโดยไม่ต้องขอความช่วยเหลือจากศูนย์บริการ โดยการตรวจสอบดังต่อไปนี้ หากยังไม่สามารถแก้ปัญหาได้หลังจากตรวจสอบตามรายการต่อไปนี้ โปรดติดต่อศูนย์บริการ

อาการ	ตรวจสอบ	วิธีแก้ไข
ผลิตภัณฑ์ไม่ทำงานเลย	• ไฟ LED บนตัวเครื่องติดกะพริบหรือไม่	เปลี่ยนแบตเตอรี่ใหม่
	• ใส่แบตเตอรี่อย่างถูกต้องหรือไม่	โปรดตรวจสอบตำแหน่งที่ใส่ (+,-)
	• เชื้อเซลล์ฟารอนั่งทำงานอย่างเหมาะสมหรือไม่	โปรดอ้างอิงคำแนะนำเกี่ยวกับเชื้อเซลล์ฟารอนั่ง (ดูหน้า 11)
ไม่มีน้ำออกมาจากหัวฉีด	• วาล์วจ่ายน้ำหลักปิดอยู่หรือไม่	เปิดวาล์วจ่ายน้ำหลัก
	• หัวฉีดตันหรือไม่	ทำความสะอาดหัวฉีดโดยใช้เบรจ
	• ติดตั้งไอซาระล้างแล้ว แต่ไม่มีน้ำออกมาจากหัวฉีด	ตรวจสอบว่าน้ำประปาของท่านเปิดอยู่หรือไม่ ตรวจสอบว่าคันโยกของวาล์วอยู่ในตำแหน่งล็อกหรือไม่
แรงดันน้ำต่ำเกินไป	• ตั้งแรงดันน้ำไประดับต่ำเกินไปหรือไม่	ปรับการตั้งค่าแรงดันน้ำ
	• หัวฉีดตันหรือไม่	ทำความสะอาดหัวฉีดโดยใช้เบรจ
	• ตะแกรงฟیلเตอร์ของแหล่งจ่ายน้ำสกปรกหรือไม่	ทำความสะอาดตะแกรงฟیلเตอร์ (ดูหน้า 17)
น้ำขังไหลแม้ว่าจะกดปุ่มหยุดแล้ว	• มีน้ำรั่วออกจากท่อไอซาระล้าง	ค้นท่อไอซาระล้างเข้าไปจนสุด
มีน้ำรั่ว แต่ไม่ได้รั่วออกมาจากหัวฉีด	• หลังจากการชำระล้าง จะใช้น้ำในการทำความสะดวกหัวฉีด นี้ไม่ใช่การทำงานผิดพลาด	
	• มีหยดน้ำเกาะอยู่รอบๆ หัวฉีดเป็นบางครั้ง หยดน้ำที่เกิดขึ้นที่ด้านล่างของผลิตภัณฑ์หลังจากทำความสะอาดหัวฉีดอาจหยดลงไปสุขภัณฑ์ นี้ไม่ใช่การทำงานผิดพลาด	
ปุ่มไม่มีการตอบสนอง	• ท่านนั่งอยู่บนไอซาระล้างหรือไม่	ฟิวเจอร์ของไอซาระล้างจะเปิดใช้งานเมื่อมีคนนั่งอยู่บนไอซาระล้างเท่านั้น
	• คันโยกของวาล์วที่ด้านข้างของไอซาระล้างอยู่ในตำแหน่งเปิดหรือไม่	หากคันโยกของวาล์วอยู่ในตำแหน่งล็อก หัวฉีดจะไม่ขึ้นออกมา

อาการ	ตรวจสอบ	วิธีแก้ไข
แผงควบคุมไม่ทำงาน	• จำเป็นต้องเปลี่ยนแบตเตอรี่หรือไม่	เปลี่ยนแบตเตอรี่
	• แบตเตอรี่อยู่ในตำแหน่งที่ถูกต้องหรือไม่ (+/-)	ใส่แบตเตอรี่ในตำแหน่งที่ถูกต้อง
	• เซ็นเซอร์ฟารองนั่งสุกเกินไปทำงานอย่างเหมาะสมหรือไม่	โปรดอ้างอิงคำแนะนำด้านเซ็นเซอร์ฟารองนั่ง
แม้ว่าไม่มีคนนั่งอยู่บนฟารองนั่ง แต่การชาร์จค้างทำงานเมื่อท่านกดปุ่ม	• มีบางอย่างติดอยู่ที่บานพับของฟารองนั่ง	นำวัตถุที่ติดอยู่ที่บานพับออก

ข้อมูลจำเพาะ

ชื่อผลิตภัณฑ์	ไอซาระล้างพลังงานแบตเตอรี่ Coway
รุ่น	BA35-A
แรงดันน้ำเข้า	0.1 MPa - 0.49 MPa (14.2 psi - 71 psi), แรงดันน้ำเข้า (สูงกว่า 1 L/min)
ขนาด	449.5 มม. (กว้าง) x 505.5 มม. (ลึก) x 130.5 มม. (สูง)
น้ำหนัก	3.45 กก.
การชำระล้างด้านหลัง	ขั้นต่ำ 800 mL/min, ฟังก์ชันทำความสะอาดหัวฉีดด้วยตนเอง
การชำระล้างด้านหน้า	ขั้นต่ำ 800 mL/min, ฟังก์ชันทำความสะอาดหัวฉีดด้วยตนเอง
เวลามาตรฐาน	การชำระล้างด้านหลัง 1 นาที, การชำระล้างด้านหน้า 1 นาที
การควบคุมแรงดันน้ำ	2 ระดับ
ตำแหน่งหัวฉีด	3 ระดับ
ชิ้นส่วนสำหรับการติดตั้ง	สกรูชนิด 2 ตัว, แหวนยางสกรูชนิด 2 ตัว, แหวนสกรูชนิด 2 ตัว, น็อตชนิด 2 ตัว ท่อไอซาระล้าง 1 ชิ้น, สกรูฝาครอบ 1 ตัว, เฟลตติดตั้ง 1 ชิ้น, สไลเดอร์ชนิด 2 ชิ้น, แป้กักยาง 1 ชิ้น, ข้อต่อสามทาง 1 ชิ้น, แบตเตอรี่ 3 ก้อน (AA)
อุณหภูมิในการทำงาน	0 °C ~ 40 °C

► ข้อมูลจำเพาะอาจเปลี่ยนแปลงเพื่อวัตถุประสงค์ในการพัฒนาประสิทธิภาพการทำงานของผลิตภัณฑ์

ประเทศไทย
ที่อยู่ : บริษัท โคเวย์ (ประเทศไทย) จำกัด 75/104-106 อาคาร โอเชียนทาวเวอร์ 2 ชั้น 38 ซอยสุขุมวิท 19 (วัฒนา) ถนนสุขุมวิท แขวงคลองเตยเหนือ เขตวัฒนา กรุงเทพมหานคร 10110 Call center: 1421

บันทึก

////////////////////////////////////

บันทึก

////////////////////////////////////

บันทึก

////////////////////////////////////

coway

www.coway.com